

Cutout Template: VL406T Panel

Note: To print actual size, set page scaling to NONE in the Adobe Acrobat print window.

Drill a .5" hole on the kerf of the center hole.

This will clear chips from the hole saw and speed the drilling of the first (center) hole.

