BP21MS2B Tech Sheet

Customer: Balboa Water Group

Part Number: 56629-02 800 Incoloy 3kW

56630-02 825 Incoloy 3kW 56631-02 Titanium 3kW

Custom Box Overlay

Box Overlay Part Number N/A

CE System Model: BP21-BP21MS2B-RCA3.0K

Software Version ID: M100 225 V36.0

Software Version: 36.0

File Name: BP2100 36.0 BP21MS2B TP4.hex

Configuration Signature: 4FEA5138

Eng. Project Number: 4776

Control Panels:

spaTouch™2 Any version (version 2.0 or later required for bba™2 fully integrated functionality)

Icon spaTouch™ Any version (version 3.36 or later required for bba™2 fully integrated functionality)

Menued spaTouch™ Any version (version 2.8 or later required for bba™2 integrated functionality)

TP900 Version 3.1 and later (Version 3.13 or later required for bba™)

TP800 Version 3.1 and later (Version 3.13 or later required for bba™; version 4.11 or later required for bba™2 integrated functionality)

TP600 Version 2.7 and later

TP400T CE Version 2.7 and later (TP400T US should <u>not</u> be used)





System Revision History

Part #	EPN	Date	Originator	Changes Made
ZT000092	4272	04-23-14	BWG	New generic MicroSilk® system, with up to 2 Pumps, plus optional Blower and optional Circ.
56629 56630 56631	4272	05-01-14	BWG	Released to production.
56629-01 56630-01 56631-01	4503	04-23-15	BWG	Add TP400T support.
56629-01 56630-01 56631-01	4776	11-01-16	BWG	Updated to latest software version, adding topside-intergrated bba™2 support. Released to production.

bba™ & bba™2 (Balboa Bluetooth Amp) connection is documented seperately.

bba™ is only integrated into graphic display panels (TP800, TP900 and spaTouch™). With TP600 the Aux button operation of bba™ must be used.

bba™2 is only integrated into graphic display panels (TP800, TP900 and spaTouch™). bba™2 does not support Aux button operation.



Basic Functions Setup 1-16

Power Requirements:

Single Service [3 wires (line, neutral, ground)] 230VAC, 50/60Hz*, 1þ, 32A, (Circuit Breaker rating = 40A max.)

Dual Service N/A

3-Service [5 wires (line 1, line 2, line 3, neutral, ground)] 230VAC line-to-neutral**, 50/60Hz*, 3b, 16A, (Circuit Breaker rating = 20A max each phase line.)

IMPORTANT - Service must include a neutral wire, with a line to neutral voltage of 230VAC.

Migrating From BP21MSSH:

If you are migrating from the BP21MSSH model to this BP21MS2B model, this chart shows how the Setup numbering has changed between these 2 models.

BP21MSSH Setup #	BP21MS2B Setup #
1	2
2	4
3	8
4	12
5	14
6	16

HiPot Testing Note:

Disconnect slip terminal with green wires from J11 prior to performing HiPot test. Failure to disconnect may cause a false failure of the test. Reconnect terminal to J11 after successful completion of HiPot test.



^{*} BP systems automatically detect 50Hz vs 60Hz.

^{** 3-}phase service measured line-to-line will read about 400V, but BP systems do not use it line-to-line.

Basic Functions Setup 1-16

System Ouputs:


Pump 1		•	Setups 5, 6, in Setups 11-	
Pump 2	230VAC	1-Speed in	12A max Setups 3–6, Setups 7–10,	
MicroSilk®	230VAC	1-Speed	8A max	30-minute timer
Blower	230VAC	1 Speed Unused in S	4A max Setups 2, 4, 6	15-minute timer 5, 8, 10, 12, 14, 16
Circ Pump		1-Speed heater pump r 20 GPM thro	2A max in Setups 1–1 ough heater	Programmable Filtration Cycles + Polling 10
0zone	230VAC		.5A max	Slaved to Circ Pump in Setups 1–10 Independent in Setups 11–16
Spa Light	10VAC	0n/0ff	1A max	240-minute timer.
A/V (Stereo)) 230VAC	Hot	5A max	Always on
Heater	3.0kW @ 24	40VAC max		

MicroSilk® is a registered trademark of Jason International



Hardware Setup

Wiring Diagram



Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



Hardware Setup

SINGLE SERVICE 230V 1b / 1x32A THREE-SERVICE 230V 1b / 3x16A

Settings

STRUCK SERVICE 250V IP / 1852A, TRINCE SERVICE 250V IP / 5810A									
LOCATION	DEVICE								
J9	NETZSTROMVERSORGUNG 2/1-GESCHWPUMPE 1 ALIMENTATION POMPE 1 A 2/1 VITESSES 2/1-SPEED PUMP 1								
J14	NETZSTROMVERSORGUNG 2/1-GESCHWPUMPE 2 ALIMENTATION POMPE 2 A 2/1 VITESSES 2/1-SPEED PUMP 2								
	P2 LINE 1 CONNECTION J19 to J43, J50 to J10								
J15	10V BELEUCHTUNG ECLAIRAGE BAIN HYDRO SPA LIGHT								
J21	KREISLAUF PUMPE POMPE DE CIRCULATION CIRC PUMP (SETUPS 7-14, 16)								
J32	OZONGENERATOR GENERATOROZONE OZONE GENERATOR								
	CIRC AND OZONE LINE 1 CONNECTION J81 to J59								
J33	TV / AV								
J40	IR RECIEVER								
J5, J8	AUX PANEL(S) - AX10, AX20, AX30, AX40								

SETUP #	CIRC PUMP	PUMP 1	PUMP 2	MICROSILK®	BLOWER	TEMP SCALE
1‡	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	2-SPEED	1-SPEED	1-SPEED	°C
2	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	2-SPEED	1-SPEED	NONE	°C
3‡	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	1-SPEED	1-SPEED	1-SPEED	°C
4	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	1-SPEED	1-SPEED	NONE	°C
5‡	PROGRAMMABLE FILTRATION + POLLING	1-SPEED	1-SPEED	1-SPEED	1-SPEED	°C
6	PROGRAMMABLE FILTRATION + POLLING	1-SPEED	1-SPEED	1-SPEED	NONE	°C
7‡	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	NONE	1-SPEED	1-SPEED	°C
8	PROGRAMMABLE FILTRATION + POLLING	2-SPEED	NONE	1-SPEED	NONE	°C
9‡	PROGRAMMABLE FILTRATION + POLLING	1-SPEED	NONE	1-SPEED	1-SPEED	°C
10	PROGRAMMABLE FILTRATION + POLLING	1-SPEED	NONE	1-SPEED	NONE	°C
11‡	NONE	2-SPEED	2-SPEED	1-SPEED	1-SPEED	°C
12	NONE	2-SPEED	2-SPEED	1-SPEED	NONE	°C
13‡	NONE	2-SPEED	1-SPEED	1-SPEED	1-SPEED	°C
14	NONE	2-SPEED	1-SPEED	1-SPEED	NONE	°C
15‡	NONE	2-SPEED	NONE	1-SPEED	1-SPEED	°C
16	NONE	2-SPEED	NONE	1-SPEED	NONE	°C

‡SETUPS WITH BLOWER REQUIRE BP2X-WIRE KIT PN30893

INSTEAD OF SETUP #6. THIS SYSTEM IS CONFIGURED IN SETUP #:

USE COPPER CONDUCTORS ONLY. EMPLOYER UNIQUEMENT DES CONDUCTEURS DE CUIVRE.

TORQUE RANGE FOR MAIN TERMINAL BLOCK (TB1): 27-30 IN. LBS. (31.1-34.5 kg cm)

water group

11-01-16

SPECIAL AMPERAGE RULE A A5 > SPECIAL AMPERAGE RULE B J1 ON STORE SETTINGS* MEMORY RESET* **⋖** A6 FXPANDER 1 MIN HTR COOLDOWN (ELEC) 47 5 MIN HTR COOLDOWN (GAS) TO RED AC (GROUP 2) **⋖** A8 NOT ASSIGNED NOT ASSIGNED ON MAIN BOARD NOT ASSIGNED **■** A9 NOT ASSIGNED NOT ASSIGNED NOT ASSIGNED ◀ A10 *SWITCH # 6 SHOULD BE SET TO OFF UPON FINAL INSTALLATION. 230V 3b 3x16A ■ A2 ■ A5 S2 S1 4A MAX 8A MAX S1 = MICROSILK® S2 = FUSED ADAPTER T0 BLOWER S2 ‡ OPTIONAL BP2X-WIRE KIT PN 30893. REQUIRED FOR SETUPS 1, 3, 5, 7, 9, 11, 13, 15. BP21MS2B - PN 56629-02 PART B

SWITCHBANK S1 OFF

DON'T ADD 1 HS PUMP W/HTR

DON'T ADD 2 HS PUMPS W/HTR ◀ A3

DON'T ADD 4 HS PUMPS W/HTR ◀ A4

TEST MODE OFF

230V 1þ

1x32A

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending. © Copyright 2012 Balboa Water Group.



SWITCHBANK S1 ON

ADD 1 HS PUMP WITH HEAT

ADD 2 HS PUMPS WITH HEAT

ADD 4 HS PUMPS WITH HEAT

TEST MODE ON

■ A1

A2 >

FOR SUPPLY CONNECTIONS,

RATED MINIMUM OF 90°C.


USE CONDUCTORS SIZED ON THE

BASIS OF 60°C AMPACITY BUT

Setup Reference Table

Setup #	Circ Pump	Pump 1	Pump 2	MicroSilk®	Blower	Temp Scale
1	Programmable Filtration + Polling	2-Speed	2-Speed	1-Speed	1-Speed	°C
2	Programmable Filtration + Polling	2-Speed	2-Speed	1-Speed	None	°C
3	Programmable Filtration + Polling	2-Speed	1-Speed	1-Speed	1-Speed	°C
4	Programmable Filtration + Polling	2-Speed	1-Speed	1-Speed	None	°C
5	Programmable Filtration + Polling	1-Speed	1-Speed	1-Speed	1-Speed	°C
6	Programmable Filtration + Polling	1-Speed	1-Speed	1-Speed	None	°C
7	Programmable Filtration + Polling	2-Speed	None	1-Speed	1-Speed	°C
8	Programmable Filtration + Polling	2-Speed	None	1-Speed	None	°C
9	Programmable Filtration + Polling	1-Speed	None	1-Speed	1-Speed	°C
10	Programmable Filtration + Polling	1-Speed	None	1-Speed	None	°C
11	None	2-Speed	2-Speed	1-Speed	1-Speed	°C
12	None	2-Speed	2-Speed	1-Speed	None	°C
13	None	2-Speed	1-Speed	1-Speed	1-Speed	°C
14	None	2-Speed	1-Speed	1-Speed	None	°C
15	None	2-Speed	None	1-Speed	1-Speed	°C
16	None	2-Speed	None	1-Speed	None	°C

System (and any replacement board)
is shipped in Setup 6





Changing Software Setups with TP800 / TP900 / spaTouch™ Menued Panel

Test Menu Access (S1, Switch 1 ON) Service Technician ONLY.


DANGER! HIGH VOLTAGE WILL BE ACCESSIBLE! SERVICE TECHNICIAN ONLY!


While the system is running, move DIP Switch 1 (on S1 on the Main circuit board) to ON. The system will enter Test Mode.

Moving DIP Switch 1 to OFF will exit Test Mode.

Software Setups

Under the TEST Menu, the Setup screen will allow changing the Setup from 1 to any number established by the Manufacturer. Changing the Setup may require wiring changes as well.







Changing Software Setups with TP600 / TP400

Test Menu Access (S1, Switch 1 ON) Service Technician ONLY.

DANGER! HIGH VOLTAGE WILL BE ACCESSIBLE! SERVICE TECHNICIAN ONLY!

While the system is running, move DIP Switch 1 (on S1 on the Main circuit board) to ON. The system will enter Test Mode.

Moving DIP Switch 1 to OFF will exit Test Mode.

As soon as Switch #1 is placed in the ON position, the temperature will show "T" after it instead of F or C, indicating the System is in Test Mode

Software Setups

Under the TEST Menu, the Setup screen will allow changing the Setup from 1 to any number established by the Manufacturer. Changing the Setup may require wiring changes as well.

You will have 1 minute to complete the setup change after you manually exit Priming Mode. (Once familiar with the process, the Setup change should take less than 15 seconds.)



When the panel displays RUN PMPS PURG AIR, press any Temperature button ONCE to exit Priming Mode. You should see "---T" where the T indicates the system is in Test Mode.



Continued on Next Page.



Changing Software Setups with TP600 / TP400 Continued


Again, You will have 1 minute to complete the setup change after you manually exit Priming Mode.


Immediately after exiting Priming Mode, press this sequence of buttons: Warm*, Light, Warm, Warm, Warm, Warm. Continue to press Warm until the diplay shows the Setup Number (S-01, S-02, etc.) you want to switch to. When the correct setup number is showing, press Light once, and the system will reset, using the newly-selected Setup from that point on.

Move DIP Switch 1 to the OFF position to take the spa out of Test Mode. °F or °C will replace °T.

Using a permanent marker, write the Setup number on the Setup label mounted inside the system lid (right). This is very important to any service person in the future who may need to replace a circuit board or system and needs to change the Setup on a replacement part while in the field.

NOTE: Changing the Setup may require wiring changes as well - refer to the wiring diagram or wiring diagram addendum.





Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending. © Copyright 2012 Balboa Water Group.



Main Screen

Equipment Expansion

Expansion Features		
Control Connection	Default	Fuse
Relay 1 (J101)	Undefined	None
Relay 7/8 (J107)	See Below	30A
	,	ly) In Setups 2, 4, 6, 8, 10, 12, 14, 16 1-Speed Blower (With Splitter & In-Line Fuse) In Setups 1, 3, 5, 7, 9, 11, 13, 15
Relay 9/10 (J108)	Undefined	None



DIP Switch Functions

Fixed-fuction DIP Switches

A1 Test Mode (normally Off).

A2 In "ON" position, add one high-speed pump (or blower) with Heater.

A3 In "ON" position, add two high-speed pumps (or 1 HS Pump and Blower) with Heater.

A4 In "ON" position, add four high-speed pumps (or 3 HS Pumps and Blower) with Heater.

A5 In "ON" position, enables Special Amperage Rule B. See Special Features section under Configuration Options for functionality with your system.

In "OFF" position, enables Special Amperage Rule A.

A6 Persistent memory reset (Used when the spa is powering up to restore factory settings as determined by software configuration).

A2, A3, and A4 work in combination to determine the number of high-speed devices and blowers that can run before the heat is disabled. i.e. A2 and A3 in the ON position and A4 in the OFF position will allow the heater to operate with up to 3 high-speed pumps (or two HS Pumps and Blower) running at the same time. Heat is disabled when the fourth high-speed pump or blower is turned on.

Note: A2/A3/A4 all off = No heat with any high-speed pump or blower.

Assignable DIP Switches

A7 In "ON" position, enables a 5-minute cooldown for some gas heaters (Cooling Time B).

In "OFF" position, enables a 1-minute cooldown for electric heaters (Cooling Time A).

Undesignated switches are not assigned a function.



Jumper Definitions

J109	Non Applicable on CE models	J109 🎅
J91	Real Time Clock Enable/Disable Note: This Jumper should NOT be shorted when the Control Panel can display time of day.	J91 🔯
J30	Do Not Use	
J31	Jumper on 1 pin with 2.0kW or smaller heater Jumper on 2 pins with a 3.0kW or higher heater	J31 🚱
J29	Heater Disable Switch Connection. If J29 is shorted by any means, the heater will not run until J29 is no longer shorted. If J29 is shorted during power-up "J29" will appear on the panel. The message can be dismissed with a button press, and is the only control panel notification of J29 being shorted. No message is displayed if J29 is shorted after power-up, but the heater will not run until J29 is no longer shorted.	J29 👸
	J29 expects a switch closure (not a voltage) as the command signal. In some areas, a local power company may offer discounts based on voluntary "power shedding" devices that may be installed	in conjunction with the spa.
J25, J26, J27	Heater Type Settings. Note: Factory Configured do not change.	J27 J25 [61 J26
J24	Jumper on center two pins (230V) when heater is running at 240V. Two Jumpers installed; one on left 2 pins and one on right 2 pins (115V) when heater is running at 120V.	J24

Warning!

Setting DIP switches or jumpers incorrectly may cause abnormal system behavior and/or damage to system components. Refer to Switchbank illustration on Wiring Configuration page for correct settings for this system. Contact Balboa if you require additional configuration pages added to this tech sheet.

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending. © Copyright 2012 Balboa Water Group.



Replacement Parts

PCBA:

Main PCBA: 56632-02 Expander PCBA: 55137

HEATER(s):

Plug + Click Heater Kit: 58300 3.0kW 800Inc

58301 3.0kW 825Inc

58302 3.0kW Titanium

Temp Sensor Kit: 53605

CABLES: N/A

FUSES:

Part Number	Amperage	Location
30136	30A	F6, F8, F1 (Expander)
20600	3A	F4
26397	1/8A	F3
30122	10A	F2, F7



General Features

Feature Pump 1 in Filter Cycle (Circ Only) Pump 1 Low Timer	Default No 15 Minutes
General Pump Timer Blower Timer MicroSilk® Timer Mister Timer	15 Minutes 15 Minutes 30 Minutes 15 Minutes
Light Timer Circ (when enabled) Cleanup Cycle	240 Minutes Programmable + Polling 30 Minutes
Cleanup cycle Cleanup as Preference setting Ozone Ozone Suppression	Yes With Heater Pump* OFF
Pump Purge Blower/MicroSilk® Purge Mister Purge	60 Seconds 30 Seconds 5 Seconds



Serial - Pumps at lowest speed

Purge Type

^{*} The heater Pump can be either a Circ Pump or Pump 1 Low.

Temperature Features

Feature Default

Temperature Display

°C

All temperatures must be specified in °F. The system converts °F to °C dynamically. If Celsius is required for default settings, choose a desired °C value that (after rounding) corresponds to a Fahrenheit value.

°C	4	5	6	7	8	9	<i>10</i>	11	12	13	14	<i>15</i>	16	17	18	19	20	21	22
°F	39	41	43	45	46	48	50	52	54	55	<i>57</i>	59	61	63	64	66	68	70	72
°C	23	24	25	26	27	28	29	30	31	<i>32</i>	33	34	<i>35</i>	36	<i>37</i>	38	39	40	
°F	73	<i>75</i>	77	79	81	82	84	86	88	90	91	93	95	97	99	100	102	104	

Hi-Range Min. Set Temp	80°F
Hi-Range Max. Set Temp	104°
Hi-Range Default Temp*	100°
Lo-Range Min. Set Temp	50°F
Lo-Range Max. Set Temp	99°F
Lo-Range Default Temp*	70°F
Freeze Threshold	44°F

Freeze Type Rotating - Pumps at Lowest Speed

Temp Lock Type Temp + Settings



^{*}May be changed by end-user (if enabled)

Time Features

Feature	Default
Time Format*	24 Hour
Filter 1 Start Hour*	20:00 (8:00 PM)
Filter 1 Duration*	2 Hours
514 C L O D C L 4	0.55
Filter Cycle 2 Default*	OFF
Filter 2 Start Hour*	08:00 (8:00 AM)
Filter 2 Duration*	15 Minutes
Light Cycle	Disabled
Light Cycle Default*	OFF
Light Cycle Start Hour*	21:00 (9:00 PM)
Light Cycle Duration*	15 Minutes
Cooling Time A	1 Minute
Cooling Time B	5 Minutes



^{*}May be changed by end-user (if enabled)

Reminder Features

Feature	Default
Reminders Shown*	Yes
Check pH	0FF
Check Sanitizer	0FF
Clean Filter	30 Days
Test GFCI	65 Days
Drain Water	100 Days
Change Cartridge	OFF
Clean Cover	0FF
Treat Wood	0FF
Change Filter	365 Days

BALB (A) Water group

^{*}May be changed by end-user (if enabled)

Special Features

Feature Default

Special Amperage Rule A No Limitation

Special Amperage Rule B Blower and MicroSilk® turn off when all pumps are on high speed

Drain Mode Disabled
Demo Mode Disabled

GFCI Trip Not Applicable for CE Models

Ozone Slaved to Heater Pump Yes in circ setups

No in non-circ setups

Dual Voltage Heater Always Input Voltage

Safety Suction Disabled

TP400 Panel Configuration

Button Layout Table for TP400T

Button #	Setup 1
1	Temperature
2	Jets 1
3	Light 1
4	MicroSilk®
LED 1	Heater ON
LED 2	Jets 1 ON
LED 3	Light ON
LED 4	MicroSilk®

TP400T CE

50332-XX

Includes Overlay PN 12741



The TP400T is mainly suitable for Setups 8, 10 & 16. In other Setups an AX10 A2 for Jets 2 and/or an AX10 A3 for Blower will be required.

MicroSilk® is a registered trademark of Jason International



TP600 Panel Configuration

Button Layout Table

Button #	Pump 2 Setups 1 - 6,	No Pump 2, Blower	No Pump 2, No Blower	
	11 - 14	Setups 7, 9, 15	Setups 8, 10, 16	
1	Jets 1	Jets 1	Jets 1	
2	Jets 2	Blower	Unused	
3	MicroSilk®	MicroSilk®	MicroSilk®	
4	Up	Up	Up	
5	Light 1	Light 1	Light 1	
6	Down	Down	Down	
LED 1	Jets 1	Jets 1	Jets 1	
LED 2	Jets 2	Blower	Unused	
LED 3	Light 1	Light 1	Light 1	
LED 4	Heat On	Heat On	Heat On	

^{*} When using setups in column 1, which operate both a Pump 2 AND a Blower, Pump 2 is on the main panel (Button2) and Blower must be operated with an Auxilliary Panel - AX10A3 on Bank 1 (J5).

See Page 21.



TP600

Panel 50439-XX - Includes Overlay 13142 - can be used with all Setups.





TP800 Panel Configuration


Button Layout Table


Feature #	Pump 2, Blower & Circ	NO Pump 2, Blower & Circ	Pump 2, NO Blower & Circ	NO Pump 2, NO Blower & Circ	Pump 2, Blower & NO Circ	NO Pump 2, Blower & NO Circ	Pump 3, NO Bl & NO Circ	NO Pump 2, NO Bl & NO Circ
	Setups 1, 3, 5	Setups 7, 9	Setups 3, 4, 6	Setups 8, 10	Setups 11, 13	Setup 15	Setups 12, 14	Setup 16
A1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
A2	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
А3	Jets 2	Blower	Jets 2	MicroSilk®	Jets 2	Blower	Jets 2	MicroSilk®
A4	Blower	MicroSilk®	MicroSilk®	Light 1	Blower	MicroSilk®	MicroSilk®	Light 1
A5	MicroSilk®	Light 1	Light 1	Invert	MicroSilk®	Light 1	Light 1	Invert
A6	Light 1	Invert	Invert	(Circ Icon)	Light 1	Invert	Invert	Undefined
A7	Invert	(Circ Icon)	(Circ Icon)	Undefined	Invert	Undefined	Undefined	Undefined
A8	(Circ Icon)	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A9	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A10	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A11	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
A12	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
A13	Jets 1	Undefined	Undefined	Undefined	Jets 1	Undefined	Undefined	Undefined
A14	Jets 2	Undefined	Undefined	Undefined	Jets 2	Undefined	Undefined	Undefined
A15	Blower	Undefined	Undefined	Undefined	Blower	Undefined	Undefined	Undefined
A16	Light	Undefined	Undefined	Undefined	Light	Undefined	Undefined	Undefined
B1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
B2	Jets 2	Blower	Jets 2	Undefined	Jets 2	Blower	Jets 2	Undefined
В3	MicroSilk®	MicroSilk®	MicroSilk®	MicroSilk®	MicroSilk®	MicroSilk®	MicroSilk®	MicroSilk®
B4	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1


Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.




Spa Screen









Shortcuts Screen







Note: Buttons 11 and 12 are not used in this configuration. Button 1 is fixed.

A Circ Icon will appear when a Circ Pump is configured.



TP800 Panel Configuration

TP800

Panel 50438-XX - Includes Overlay 13141 - can be used with all Setups.



Panel 50318-XX - Includes Overlay 12719 - can be used with Setups 1-6 and 11-14.



Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



TP900 Panel Configuration


Button Layout Table

Button #	Pump 2, Blower & Circ	NO Pump 2, Blower & Circ	Pump 2, NO Blower & Circ	NO Pump 2, NO Blower & Circ	Pump 2, Blower & NO Circ	NO Pump 2, Blower & NO Circ	Pump 3, NO Bl & NO Circ	NO Pump 2, NO Bl & NO Circ
	Setups 1, 3, 5	Setups 7, 9	Setups 3, 4, 6	Setups 8, 10	Setups 11, 13	Setup 15	Setups 12, 14	Setup 16
1	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
2	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
3	Jets 2	Blower	Jets 2	MicroSilk®	Jets 2	Blower	Jets 2	MicroSilk®
4	Blower	MicroSilk®	MicroSilk®	Light 1	Blower	MicroSilk®	MicroSilk®	Light 1
5	MicroSilk®	Light 1	Light 1	Invert	MicroSilk®	Light 1	Light 1	Invert
6	Light 1	Invert	Invert	(Circ Icon)	Light 1	Invert	Invert	Undefined
7	Invert	(Circ Icon)	(Circ Icon)	Undefined	Invert	Undefined	Undefined	Undefined
8	(Circ Icon)	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
9	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
10	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
11	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
12	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
13	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
14	Jets 2	Blower	Jets 2	MicroSilk®	Jets 2	Blower	Jets 2	MicroSilk®
15	MicroSilk®	MicroSilk®	MicroSilk®	Light	MicroSilk®	MicroSilk®	MicroSilk®	Light
16	Light	Light	Light	Invert	Light	Light	Light	Invert

A Circ Icon will appear when a Circ Pump is configured.



TP900 Panel Configuration



56629-02/56630-02/56631-02_97_A 11-28-16

Template 56377 10-05-12

26

Auxilliary Panel Features on Bank 1*

Feature	Default
Aux Button A1	Jets 1
Aux Button A2	Jets 2
Aux Button A3	Blower
Aux Button A4	Light

Auxilliary Panel Features on Bank 2*

Feature	Default
Aux Button A5	Jets 1
Aux Button A6	Jets 2
Aux Button A7	MicroSilk®
Aux Button A8	Light

*Bank 1 consists of J5 on the Main Circuit Board. Bank 2 consists of J8 on the Main Circuit Board.

Buttons that are assigned to equipment that is not defined in a Setup will not do anything in that Setup.

Aux Connection Splitter PN 25257 may be required.



Auxilliary Panel Features

AX10 Panels on Bank 1*

A1, AX10A1 No 0/L 52803
A2, AX10A2 No 0/L 52804
A3, AX10A3 No 0/L 52805 ►
A4, AX10A4 No 0/L 52806



Call Customer Service for additional information about Auxiliary Panels.

AX10 Panels on Bank 2*

A5, AX10A1	No O/L	52803
A6, AX10A2	No O/L	52804
A7, AX10A3	No O/L	52805
A8, AX10A4	No O/L	52806


*Bank 1 consists of J5 on the Main Circuit Board.

Bank 2 consists of J8 on the Main Circuit Board.

Aux Connection Splitter PN 25257 may be required.

AX20


AX20 A1A2	No O/L	52800
AX20 A1A3	No O/L	52801
AX20 A1A4	No O/L	52802



AX20 Auxiliary Panel plugged into Bank 1 will operate A1 + A2, A3 or A4. AX20 Auxiliary Panel plugged into Bank 2 will operate A5 + A6, A7 or A8.

AX40

AX40 No 0/L 52799




AX40 Auxiliary Panel plugged into Bank 1 will operate A1 + A2, A3 and A4. AX40 Auxiliary Panel plugged into Bank 2 will operate A5 + A6, A7 and A8.



Remote Panel Features

Feature	Default
Remote Button A1	Jets 1
Remote Button A2	Jets 2
Remote Button A3	Undefined
Remote Button A4	Blower
Remote Button A5	Light
Remote Button A6	Undefined
Remote Button A7	Undefined
Remote Button A8	Undefined



Buttons that are assigned to equipment that is not defined in a Setup will not do anything in that Setup.

Template 56377 10-05-12

Remote Panel Part Number

Overlay Part Number

29

56629-02/56630-02/56631-02_97_A 11-28-16