BP21P4BC Tech Sheet

Customer: Balboa Water Group

Part Number: 56626-03 825 Incoloy 3kW

> Titanium 3kW 56627-03

Custom Box Overlay

Box Overlay Part Number N/A

CE System Model: BP21-BP21P4BC-RCA3.0K

Software Version ID: M100 225 V65.0

Software Version: 65.0

File Name: BP2100 65.0 BP21P4BC TP6.hex

Configuration Signature: 99DB30F1

Eng. Project Number: 5663

Control Panels:

Template 56377 10-05-12

Any version (version 3.2 or later required for Clim8zone™ heat pump support) spaTouch™3

spaTouch™2 Any version (version 2.19 or later required for CHROMAZON∃™ support; version 2.36 or later required for Clim8zone™ heat pump support)

Icon spaTouch™ Any version (version 3.36 or later required for bba[™]2 fully integrated functionality)

Menued spaTouch™ Any version (version 2.8 or later required for bba™2 integrated functionality)

Version 3.1 and later (Version 3.13 or later required for bba™) TP900

Version 3.1 and later (Version 3.13 or later required for bba™; version 4.11 or later required for bba™2 integrated functionality) TP800

TP700 Any version

Version 2.7 and later (Version 2.12 or later required for bba™/bba™2 On/Off control via menu) TP600





System Revision History

Part #	EPN	Date	Originator	Changes Made
ZT000084	4248	04-10-14	BWG	New generic BP2100 with 4 Pumps plus optional blower and/or Circ.
56625 56626 56627	4248	05-01-14	BWG	Released to production.
56625-01 56626-01 56627-01	4776	10-27-16	BWG	Updated to latest software version, adding topside-intergrated bba™2 support. Also added TP600 support. Released to production.
56626-02 56627-02	5098	01-27-21	BWG	Redesigned BP2100 board + updated software to support CHROMAZON∃™ & M8. 56625-XX (800 Incoloy version) discontinued.
56626-03 56627-03	5663	06-09-22	BWG	Update to support Clim8zone™ heat pump. Update transformer fuse.

bba™2 / bba™3 (Balboa Bluetooth Amp) connection is documented separately.

bba[™]2 / bba[™]3 is integrated into graphic display panels (TP700, TP800, TP900 and spaTouch[™]).

With TP600, use the "BT" entry on the menu to toggle bba™2 / bba™3 power On/Off.



Basic Functions Setup 1-8

Power Requirements:

Single Service [3 wires (line, neutral, ground)] – RESTRICTED OPERATIONS (See page 5) 230VAC, 50/60Hz*, 1þ, 32A, (Circuit Breaker rating = 40A max.)

Dual Service N/A

3-Service [5 wires (line 1, line 2, line 3, neutral, ground)] 230VAC line-to-neutral**, 50/60Hz*, 3þ, 16A, (Circuit Breaker rating = 20A max each phase line.)

HiPot Testing Note:

Disconnect slip terminal with green wires from J6 prior to performing HiPot test. Failure to disconnect may cause a false failure of the test. Reconnect terminal to J6 after successful completion of HiPot test.

IMPORTANT - Service must include a neutral wire, with a line to neutral voltage of 230VAC.

In 3x16A Service:

Pump 2 and Blower (if any) are on one service.

Pump 3, Pump 4, and the heater are on another service.

Everything else is on the remaining service.



^{*} BP systems automatically detect 50Hz vs 60Hz. However, power frequency (50Hz vs 60Hz) is just one of many differences between North American (UL) and CE power, and it is because of these other differences that different BP systems must be used for UL vs CE territories. Also, there are a few countries that use CE power but 60 Hz (such as South Korea) which need CE systems, and a few countries that use UL power but 50 Hz which need UL systems.

^{** 3-}phase service measured line-to-line will read about 400V, but BP systems do not use it line-to-line.

Basic Functions Setup 1-8

System Ouputs:

Pump 1		•	11A max* Setups 4 & 5 in Setups 6-8 ough heater	15-minute timer for High Speed, 15-Minute timer for Low Speed
Pump 2	230VAC	•	11A max* Setups 2-5, 7	15-minute timer -8
Pump 3	230VAC	1-Speed	8A max*	15-minute timer
Pump 4	230VAC	1-Speed	8A max*	15-minute timer
Blower	230VAC	1 Speed Unused in S	5A max* Setups 1, 3, 5,	15-minute timer . 6 & 8
Circ Pump		1-Speed leater pump i 20 GPM thro	2A max* in Setups 1–5 ough heater	Programmable Filtration Cycles + Polling
Ozone	230VAC		.5A max*	Slaved to Circ Pump in Setups 1-5 Independent in Setups 6-8
Spa Light	10VAC	0n/0ff	2A*** max	240-minute timer.
AV + C8Z**	230VAC	Hot	2A*+8A max	Always on
Heater	3.0kW @ 24	OVAC max		

^{*} These are individual maximums but depending on the electrical services they may need to be reduced. See restrictions on next page.



^{** 2}A max limit is shared by On/Off Spa Light <u>and</u> CHROMAZON∃™.

^{***} Optional splitter PN 22934 can be used to connect two things, such as an audio device and Clim8zone™(C8Z), to J33.

Basic Functions Setup 1-8

Restrictions:

In 3x16A, all equipment (if within the individual maximums listed on page 4) can run together, except the heater turns off with any high-speed pump or blower. (DIP switch A5 must be OFF.)

In 1x32A, DIP switch A5 must be ON. With DIP Switch A5 ON, only 3 pumps (any 3 pumps) can be ON at high speed at any one time, and the blower will not run when 3 pumps are ON at high speed.

In 1x40A, with DIP switch A5 ON, it works just like at 1x32A.

To be able to use 1x40A with DIP switch A5 OFF (ie, no restrictions except for the heater), all the 230V equipment used in the spa (except for the heater) must add up to no more than 39.5 Amps. This means all 4 pumps, the blower (if any), the circ pump (if any), the ozone, and A/V (if any). (There is 0.5 Amps at 230V reserved for board and panel power as well as 10V equipment including the spa lights. That is why the 230V equipment must add up to 39.5 Amps rather than 40.0 Amps.)


See this chart for some 1x40A examples:

Pump 1	11A	11A	8.5A
Pump 2	11A	11A	8.5A
Pump 3	8A	8A	7.5A
Pump 4	8A	8A	7.5A
Blower	3A	None	3A
Circ	2A	None	2a
0zone	0.5A	0.5A	0.5A
A/V	None	None	2A
Total	43.5A	38.5A	39.5A
Will it work?	No	Yes	Yes



Hardware Setup

Wiring Diagram



Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



Hardware Setup

Settings

SINGLE SE	RVICE 230V 1p / 1x32A, THREE-SERVICE 230V 3p / 3x16A					SWITCHBANK S1 OFF		SWITCHBANK S1 ON
LOCATION	DEVICE	MAX AMPS			†	TEST MODE OFF	■ A1	TEST MODE ON
J9	NETZSTROMVERSORGUNG 2-GESCHWPUMPE 1	11A			230V 1þ	DON'T ADD 1 HS PUMP W/HTR	■ A2	ADD 1 HS PUMP WITH HEAT
	ALIMENTATION POMPE 1 A 2 VITESSES 2-SPD PUMP 1	IIA			1x32A	DON'T ADD 2 HS PUMPS W/HTR	⋖ A3	ADD 2 HS PUMPS WITH HEAT
J14	2/1-SPD PUMP 2 + BLOWER					DON'T ADD 4 HS PUMPS W/HTR	⋖ A4	ADD 4 HS PUMPS WITH HEAT
	NETZSTROMVERSORGUNG 2/1-GESCHWPUMPE 2 + SPRUDELGEBLASE	11A + 5A				SPECIAL AMPERAGE RULE A	A5 >	SPECIAL AMPERAGE RULE B
	ALIMENTATION POMPE 2 A 2/1 VITESSES + VENTILATEUR					STORE SETTINGS*	⋖ A6	MEMORY RESET*
J15	10V BELEUCHTUNG ECLAIRAGE BAIN HYDRO SPA LIGHT	2A* (@10V)	i i	TO J14 ON	1	1 MIN HTR COOLDOWN (ELEC)	⋖ A7	5 MIN HTR COOLDOWN (GAS)
J21	KREISLAUF PUMPE POMPE DE CIRCULATION CIRC PUMP	2A	i	MAIN BOARD	!	NOT ASSIGNED	≪ A8	NOT ASSIGNED
J32	OZONGENERATOR GENERATOROZONE OZONE GENERATOR	0.5A	I TO CO	OUP 2		NOT ASSIGNED	⋖ A9	NOT ASSIGNED
J33	AV + CLIM8ZONE™ (C8Z)	2A + 8A		N BOARD	- 1	NOT ASSIGNED	■ A10	NOT ASSIGNED
J44	HEATER	3.0kW	I ON THE		i	*SWITCH # 6 SHOULD BE SET TO OFF	UDON CINAL IN	CTALL ATTOM
* 2A LIMIT	IS SHARED BY J15 SPA LIGHT <u>ONA</u> THE STATE OF THE STATE					SHETCH # O SHOOLD BE SET TO CH		230V 3b 3x16
CETUD	OTDO DUND DUND 1 DUND 0 DUND 0	DUMP 4 DIGUED	TEMP.	1 4111	i		I OFF	
SETUP "	CIRC PUMP PUMP 1 PUMP 2 PUMP 3	PUMP 4 BLOWER	TEMP I	/	1		 	
#			SCALE	ş	I		I <u> </u>	<u> </u>
1 PR00	GRAMMABLE FILTRATION + POLLING 2-SPEED 2-SPEED 1-SPEED	1-SPEED NONE	°C		!		■	
	GRAMMABLE FILTRATION + POLLING 2-SPEED 1-SPEED 1-SPEED	1-SPEED 1-SPEED	°C PR	GR.	-		ı∟	
3 PR00	GRAMMABLE FILTRATION + POLLING 2-SPEED 1-SPEED 1-SPEED	1-SPEED NONE	°C I 🗒	RED	- 1		- 1	TB1
4 PR00	GRAMMABLE FILTRATION + POLLING 1-SPEED 1-SPEED 1-SPEED	1-SPEED 1-SPEED	°C I	위 큐	i		3 BR	* 💛
5 PR00	GRAMMABLE FILTRATION + POLLING 1-SPEED 1-SPEED 1-SPEED	1-SPEED NONE	°C I		i		1 BRI	
6	NONE 2-SPEED 2-SPEED 1-SPEED			S2 S1	1		ı ı BLU	
7	NONE 2-SPEED 1-SPEED 1-SPEED	1-SPEED 1-SPEED	°C 5/	A MAX 11A MAX	1		2 BRI	
8	NONE 2-SPEED 1-SPEED 1-SPEED	1-SPEED NONE	°C 7	ን	I.			3 3 S
			;	<u> </u>	!		¦Œ	155 155 156 156 156 156 156 156 156 156
		INSTEAD OF	l i	SPLITTER OPTIONS:	-		ΙŒ	,
		SETUP #5,	1		- 1		I	REMOVE RELOCATE 3
		THIS SYSTEM IS		S1 = PUMP 2 S2 = FUSED ADAPTER	. i		1	J51-J58 J41-J53 ⇒J54
\mathbf{H}'	ALB@A	CONFIGURED IN	1!	32 = FUSED ADAPTER	1		1	J52-J36 J60-J 1 2 ⇒J45
		SETUP #:	!		L			
wa1	ter group		- !		C			
			i			10A	BLOWER	.
	TOROUE RANGE FOR		i			T0	SETUPS	`
	MAIN TERMINAL BLOCK (TB1):		i			⊒ S2 	2, 4, &	7
	27-30 IN. LBS.		1				ONLY	_ J i
	(31.1-34.5 kg cm)		Ι			***FUSED ADAPTER		·
			ı ‡ OF	PIIONAL BP2X-WIRE K	II PN 308	93 - REQUIRED FOR SETUPS	2, 4, & 7	l I
EUD SIIDDI A	CONNECTIONS. USE COPPER CONDUCTORS ONLY.							
	TORS SIZED ON THE EMPLOYER UNIQUEMENT			1	2-22-22			
OSE CONDUC	IORS SIZED ON THE FULL OLDER CONTROLLED BE CHILDE			_		D 4 D 0 D 1 1		

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.

DES CONDUCTEURS DE CUIVRE.



PART B

BP21P4BC - PN 56626-03

BASIS OF 60°C AMPACITY BUT

RATED MINIMUM OF 90°C.

Setup Reference Table

Setup #	Circ Pump	Pump 1	Pump 2	Pump 3	Pump 4	Blower	Temp Scale
1	Programmable Filtration + Polling	2-Speed	2-Speed	1-Speed	1-Speed	None	°C
2	Programmable Filtration + Polling	2-Speed	1-Speed	1-Speed	1-Speed	1-Speed	°C
3	Programmable Filtration + Polling	2-Speed	1-Speed	1-Speed	1-Speed	None	°C
4	Programmable Filtration + Polling	1-Speed	1-Speed	1-Speed	1-Speed	1-Speed	°C
5	Programmable Filtration + Polling	1-Speed	1-Speed	1-Speed	1-Speed	None	°C
6	None	2-Speed	2-Speed	1-Speed	1-Speed	None	°C
7	None	2-Speed	1-Speed	1-Speed	1-Speed	1-Speed	°C
8	None	2-Speed	1-Speed	1-Speed	1-Speed	None	°C

System (and any replacement board)
is shipped in Setup 5

Color	Output							
Key								
	XP332 and Splitter							
	J14 (Aux) and splitter and in-line Blower fuse							
	J14 (Aux) on Main Board							

Changing Software Setups with spaTouch™ Icon-Driven Panels


Test Menu Access (S1, Switch 1 ON) Service Technician ONLY.

DANGER! HIGH VOLTAGE WILL BE ACCESSIBLE! SERVICE TECHNICIAN ONLY!

While the system is running, move DIP Switch 1 (on S1 on the Main circuit board) to ON. The system will enter Test Mode.

Moving DIP Switch 1 to OFF will exit Test Mode.

ON 1 10 S1




To Change Software Setups:

While in Test Mode, press the indicated icons to move from screen to screen.








on the spaTouch 2 Panel are similar. The main

difference is that the spaTouch 2 display is



Once on the Setup Selection screen, press the Up or Down icon to select the desired Setup Number, then press the Check Mark icon to confirm and to have the spa restart.

After the system restarts, you may see a message that "The settings have been reset"; this is normal after changing Setups with DIP Switch 6 in the OFF position. Press "Clear" to dismiss this message.



Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.

Changing Software Setups with TP800 / TP900 / spaTouch™ Menued Panel

Test Menu Access (S1, Switch 1 ON) Service Technician ONLY.


DANGER! HIGH VOLTAGE WILL BE ACCESSIBLE! SERVICE TECHNICIAN ONLY!


While the system is running, move DIP Switch 1 (on S1 on the Main circuit board) to ON. The system will enter Test Mode.

Moving DIP Switch 1 to OFF will exit Test Mode.

Software Setups

Under the TEST Menu, the Setup screen will allow changing the Setup from 1 to any number established by the Manufacturer. Changing the Setup may require wiring changes as well.








Changing Software Setups with TP600 / TP400

Test Menu Access (S1, Switch 1 ON) Service Technician ONLY.

DANGER! HIGH VOLTAGE WILL BE ACCESSIBLE! SERVICE TECHNICIAN ONLY!

While the system is running, move DIP Switch 1 (on S1 on the Main circuit board) to ON. The system will enter Test Mode.

Moving DIP Switch 1 to OFF will exit Test Mode.



Software Setups

Under the TEST Menu, the Setup screen will allow changing the Setup from 1 to any number established by the Manufacturer. Changing the Setup may require wiring changes as well.

You will have 1 minute to complete the setup change after you manually exit Priming Mode. (Once familiar with the process, the Setup change should take less than 15 seconds.)











When the panel displays RUN PMPS PURG AIR, press any Temperature button ONCE to exit Priming Mode. You should see "---T" where the T indicates the system is in Test Mode.



Continued on Next Page.



Changing Software Setups with TP600 / TP400 Continued


Again, You will have 1 minute to complete the setup change after you manually exit Priming Mode.

Immediately after exiting Priming Mode, press this sequence of buttons: Warm*, Light, Warm, Warm, Warm, Warm. Continue to press Warm until the diplay shows the Setup Number (S-01, S-02, etc.) you want to switch to. When the correct setup number is showing, press Light once, and the system will reset, using the newly-selected Setup from that point on.

Move DIP Switch 1 to the OFF position to take the spa out of Test Mode. °F or °C will replace °T.

Using a permanent marker, write the Setup number on the Setup label mounted inside the system lid (right). This is very important to any service person in the future who may need to replace a circuit board or system and needs to change the Setup on a replacement part while in the field.

NOTE: Changing the Setup may require wiring changes as well - refer to the wiring diagram or wiring diagram addendum.



Approx. 5 sec.

....

Main Screen

RANGE A FITRI

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending. © Copyright 2012 Balboa Water Group.

12



*If the Control Panel does not have a Warm (Up) button, but

rather a single Temp button, use the Temp button in place of the Warm button in the instruction above. (The flow chart

assumes a single Temperature Button.)

THIS SYSTEM IS

CONFIGURED AS SETUP #

56626-03_56627-03_97_D 12-07-23

Equipment Expansion

Expansion Features Control Connection

Relay 1 (J101) Undefined None Relay 7/8 (J107) See Below 30A

Default

1-Speed Pump 3 And 1-Speed Pump 4 (With Splitter)

Fuse

Relay 9/10 (J108) Undefined None



13

DIP Switch Functions

Fixed-fuction DIP Switches

Test Mode (normally Off). A1

In "ON" position, add one high-speed pump (or blower) with Heater. A2

In "ON" position, add two high-speed pumps (or 1 HS Pump and Blower) with Heater. **A**3

Α4 In "ON" position, add four high-speed pumps (or 3 HS Pumps and Blower) with Heater.

In "ON" position, enables Special Amperage Rule B. See Special Features section under Configuration Options for functionality with your system. Α5

In "OFF" position, enables Special Amperage Rule A.

Persistent memory reset (Used when the spa is powering up to restore factory settings as determined by software configuration). Α6

A2, A3, and A4 work in combination to determine the number of high-speed devices and blowers that can run before the heat is disabled. i.e. A2 and A3 in the ON position and A4 in the OFF position will allow the heater to operate with up to 3 high-speed pumps (or two HS Pumps and Blower) running at the same time. Heat is disabled when the fourth high-speed pump or blower is turned on.

Note: A2/A3/A4 all off = No heat with any high-speed pump or blower.

Assignable DIP Switches

Template 56377 10-05-12

Α7 In "ON" position, enables a 5-minute cooldown for some gas heaters (Cooling Time B).

In "OFF" position, enables a 1-minute cooldown for electric heaters (Cooling Time A).

Undesignated switches are not assigned a function.



Jumper Definitions

J109	Non Applicable on CE models	J109 🎅
J91	Real Time Clock Enable/Disable Note: This Jumper should NOT be shorted when the Control Panel can display time of day.	J91 ©a
J30	Do Not Use	
J31	Jumper on 1 pin with 2.0kW or smaller heater Jumper on 2 pins with a 3.0kW or higher heater	J31 🎉
J29	Heater Disable Switch Connection. If J29 is shorted by any means, the heater will not run until J29 is no longer shorted. If J29 is shorted during power-up "J29" will appear on the panel. The message can be dismissed with a button press, and is the only control panel notification of J29 being shorted. No message is displayed if J29 is shorted after power-up, but the heater will not run until J29 is no longer shorted.	J29 👸
	J29 expects a switch closure (not a voltage) as the command signal. In some areas, a local power company may offer discounts based on voluntary "power shedding" devices that may be installed.	I in conjunction with the spa.
J25, J26, J27	Heater Type Settings. Note: Factory Configured do not change.	J27 J25 [21] J26
J24	Jumper on center two pins (230V) when heater is running at 240V. Two Jumpers installed; one on left 2 pins and one on right 2 pins (115V) when heater is running at 120V.	J24 © 15V

Warning!

Setting DIP switches or jumpers incorrectly may cause abnormal system behavior and/or damage to system components. Refer to Switchbank illustration on Wiring Configuration page for correct settings for this system. Contact Balboa if you require additional configuration pages added to this tech sheet.

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



Replacement Parts

PCBA:

Main PCBA: 59538-01 Expander PCBA: 59097

HEATER(s):

Plug + Click Heater Kit: 58107R16 3.0kW 825Inc

55626R16 3.0kW Titanium

Temp Sensor Kit: 53605

CABLES: 25093 P3/P4 Adapter

FUSES:

Part Number	Amperage*	Location
30136	30A	F6, F8, F1 (Expander)
26307	2A	F4
24825	0.125A	F3
26904	10A	F2, F7
26976	3.15A	F5

^{*} The amperages shown above are only intended for identifying fuses on our boards. They are not complete descriptions of those fuses. Please use the part numbers at the left to order fuses directly from Balboa.



General Features

Feature	Default
Pump 1 in Filter Cycle (Circ Only)	No
Pump 1 Low Timer	15 Minutes
General Pump Timer	15 Minutes
Blower Timer	15 Minutes
Mister Timer	15 Minutes
Light Timer	240 Minutes
Circ (when enabled)	Programmable + Polling

Cleanup Cycle 30 Minutes

Cleanup as Preference setting Ye.

Ozone With Heater Pump*

Ozone Suppression OFF

Pump Purge60 SecondsBlower Purge30 SecondsMister Purge5 Seconds

Purge Type Serial - Pumps at lowest speed



^{*} The heater Pump can be either a Circ Pump or Pump 1 Low.

Temperature Features

Feature Default

Temperature Display °C

All temperatures must be specified in °F. The system converts °F to °C dynamically. If Celsius is required for default settings, choose a desired °C value that (after rounding) corresponds to a Fahrenheit value.

°C	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
°F	39	41	43	45	46	48	50	52	54	55	<i>57</i>	59	61	63	64	66	68	70	72
°C	23	24	25	26	27	28	29	30	31	<i>32</i>	33	34	<i>35</i>	36	<i>37</i>	38	39	40	
°F	73	<i>75</i>	77	79	81	82	84	86	88	90	91	93	95	97	99	100	102	104	

Hi-Range Min. Set Temp	80°F
Hi-Range Max. Set Temp	104°
Hi-Range Default Temp*	100°
Lo-Range Min. Set Temp	50°F
Lo-Range Max. Set Temp	99°F
Lo-Range Default Temp*	70°F
Freeze Threshold	44°F

Freeze Type Rotating - Pumps at Lowest Speed

Temp Lock Type Temp + Settings



^{*}May be changed by end-user (if enabled)

Time Features

Feature	Default
Time Format*	24 Hour
Filter 1 Start Hour*	20:00 (8:00 PM)
Filter 1 Duration*	2 Hours
Filter Cycle 2 Default*	OFF
Filter 2 Start Hour*	08:00 (8:00 AM)
Filter 2 Duration*	15 Minutes
Light Cycle	Disabled
Light Cycle Default*	OFF
Light Cycle Start Hour*	21:00 (9:00 PM)
Light Cycle Duration*	15 Minutes
Cooling Time A	1 Minute
Cooling Time B	5 Minutes



^{*}May be changed by end-user (if enabled)

Reminder Features

Feature	Default
Reminders Shown*	Yes
Check pH	0FF
Check Sanitizer	0FF
Clean Filter	30 Days
Test GFCI	65 Days
Drain Water	100 Days
Change Cartridge	OFF
Clean Cover	0FF
Treat Wood	0FF
Change Filter	365 Days

BALB (A) Water group

^{*}May be changed by end-user (if enabled)

Special Features

Feature Default

Special Amperage Rule A No Limitation

Special Amperage Rule B 3 high-speed pumps max. Blower turns off with 3 high speed pumps

Drain Mode Disabled
Demo Mode Disabled

GFCI Trip Not Applicable for CE Models

Ozone Slaved to Heater Pump Yes in circ setups

No in non-circ setups

Dual Voltage Heater Always Input Voltage

Safety Suction Disabled

21

56626-03_56627-03_97_D 12-07-23

TP600 Panel Configuration

Button Layout Table

Button #	Setups 1 - 8
1	Jets 1
2	Jets 2
3	Jets 3
4	Temperature
5	Light 1
6	Jets 4
LED 1	Jets 1
LED 2	Jets 2
LED 3	Light 1
LED 4	Heat On



In all Setups, the button labeled "AUX" on overlay 13579 (shown below) controls Jets 4. In Setups 2, 4, 7 (which have a Blower), an AX10A3 auxiliary panel plugged into J5 (Bank 1) must be used to control the Blower.





Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending. © Copyright 2012 Balboa Water Group.

TP800 Panel Configuration

Button Layout Table

	layout lable	NO DI	DI 0 11 01	
Feature #	Blower & Circ	NO Blower & Circ	Blower & No Circ	NO Blower & No Circ
"	Setups 2 & 4	Setups 1, 3, & 5	Setup 7	Setups 6 & 8
A1	N/A	N/A	N/A	N/A
A2	Jets 1	Jets 1	Jets 1	Jets 1
А3	Jets 2	Jets 2	Jets 2	Jets 2
A4	Jets 3	Jets 3	Jets 3	Jets 3
A5	Jets 4	Jets 4	Jets 4	Jets 4
A6	Blower	Light 1	Blower	Light 1
A7	Light 1	Invert	Light 1	Invert
A8	Invert	(Circ Icon)	Invert	Undefined
A9	(Circ Icon)	Undefined	Undefined	Undefined
A10	Undefined	Undefined	Undefined	Undefined
A11	N/A	N/A	N/A	N/A
A12	N/A	N/A	N/A	N/A
A13	Jets 1	Jets 1	Jets 1	Jets 1
A14	Jets 2	Jets 2	Jets 2	Jets 2
A15	Jet 3	Jet 3	Jet 3	Jet 3
A16	Jet 4	Jet 4	Jet 4	Jet 4
B1	Jets 1	Jets 1	Jets 1	Jets 1
B2	Jets 2	Jets 2	Jets 2	Jets 2
В3	Blower	Jets 3	Blower	Jets 3
B4	Light 1	Light 1	Light 1	Light 1

Overlay Part Number 12512.




Button labled "AUX" controls Blower in Setups 2, 4, & 7, and controls Jets 3 in all other Setups.





TP800 Panel Configuration

Template 56377 10-05-12


Spa Screen









Shortcuts Screen







Note: Buttons 11 and 12 are not used in this configuration.

Button 1 is fixed.

A Circ Icon will appear when a Circ Pump is configured.



TP900 Panel Configuration


Button Layout Table

Feature	Blower & Circ	NO Blower & Circ	Blower & No Circ	NO Blower &
#	Setups 2 & 4	Setups 1, 3, & 5	Setup 7	No Circ
		,	·	Setups 6 & 8
A1	N/A	N/A	N/A	N/A
A2	Jets 1	Jets 1	Jets 1	Jets 1
А3	Jets 2	Jets 2	Jets 2	Jets 2
A4	Jets 3	Jets 3	Jets 3	Jets 3
A5	Jets 4	Jets 4	Jets 4	Jets 4
A6	Blower	Light 1	Blower	Light 1
A7	Light 1	Invert	Light 1	Invert
A8	Invert	(Circ Icon)	Invert	Undefined
А9	(Circ Icon)	Undefined	Undefined	Undefined
A10	Undefined	Undefined	Undefined	Undefined
11	N/A	N/A	N/A	N/A
12	N/A	N/A	N/A	N/A
13	Jets 1	Jets 1	Jets 1	Jets 1
14	Jets 2	Jets 2	Jets 2	Jets 2
15	Jets 3	Jets 3	Jets 3	Jets 3
16	Jet 4	Jet 4	Jet 4	Jet 4

A Circ Icon will appear when a Circ Pump is configured.



TP900 Panel Configuration



Auxiliary Panel Features on Bank 1*

Feature	Default	
Aux Button A1	Jets 1	
Aux Button A2	Jets 2	
Aux Button A3	Blower	
Aux Button A4	Light	

Auxiliary Panel Features on Bank 2*

Feature	Default
Aux Button A5	Jets 1
Aux Button A6	Jets 2
Aux Button A7	Jets 3
Aux Button A8	Jets 4

Buttons that are assigned to equipment that is not defined in a Setup will not do anything in that Setup.

*Bank 1 consists of J5 on the Main Circuit Board.

Bank 2 consists of J8 on the Main Circuit Board.

Aux Connection Splitter PN 25257 may be required.

56626-03_56627-03_97_D 12-07-23



Auxiliary Panel Features

AX10 Panels on Bank 1*

A1, AX10A1 No 0/L 52803
A2, AX10A2 No 0/L 52804
A3, AX10A3 No 0/L 52805 ▶
A4, AX10A4 No 0/L 52806



Call Customer Service for additional information about Auxiliary Panels.

AX10 Panels on Bank 2*

A5, AX10A1	No O/L	52803
A6, AX10A2	No O/L	52804
A7, AX10A3	No O/L	52805
A8 AX10A4	No O/I	52806


*Bank 1 consists of J5 on the Main Circuit Board.

Bank 2 consists of J8 on the Main Circuit Board.

Aux Connection Splitter PN 25257 may be required.

AX20


AX20 A1A2 No 0/L 52800 AX20 A1A3 No 0/L 52801 AX20 A1A4 No 0/L 52802



AX20 Auxiliary Panel plugged into Bank 1 will operate A1 + A2, A3 or A4. AX20 Auxiliary Panel plugged into Bank 2 will operate A5 + A6, A7 or A8.

AX40

AX40 No 0/L 52799




AX40 Auxiliary Panel plugged into Bank 1 will operate A1 + A2, A3 and A4. AX40 Auxiliary Panel plugged into Bank 2 will operate A5 + A6, A7 and A8.



Remote Panel Features

Feature	Default
Remote Button A1	Jets 1
Remote Button A2	Jets 2
Remote Button A3	Undefined
Remote Button A4	Jets 3
Remote Button A5	Jets 4
Remote Button A6	Undefined
Remote Button A7	Undefined
Remote Button A8	Undefined



Buttons that are assigned to equipment that is not defined in a Setup will not do anything in that Setup.

Template 56377 10-05-12

Remote Panel Part Number

Overlay Part Number

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.

56626-03_56627-03_97_D 12-07-23

